

railcore

O) Bed

Written By: Ben Withem





PARTS:

- [M3 x 20 Socket Head Screw](#) (3)
- [M3 Washer](#) (3)
- [1/4" Rubber Washer](#) (3)
- [M3 Nylock Nut](#) (3)
- [Mini Aluminum Bed](#) (1)
- [Mini Silicon Heater](#) (1)

Step 1 — Install Heater



- Remove backing revealing 3M adhesive and install the silicon heater as shown in the image.

Step 2 — Install Bed



- The bolt stack for mounting the bed is made up of (1) M3 x 25 socket head screw, (1) set of leveling washers, (1) 1/4" rubber washer, (1) M3 washer, and (1) nylock M3 nut.
- The socket head should go in the milled cutout of the bed, and the bed should sit on the stack of the leveling washers on top of the Z yoke.
- The rubber washer, M3 washer and M3 nylock nut will be below the Z yoke.

⚠ The latest version of the Z yokes have three slots. To match the kit configuration, attach the bed to the yokes using the mounting slots closest to the front of the printer.

i Wiring should hang off the right side of the bed when installed.

- Tighten the nylock nuts, attaching the bed to the three Z yokes.